

WILDEN

NEW WILDEN PUMP REPAIR KITS CHEAPER. FASTER. EASIER.

Wilden's new parts kit program significantly lowers costs and simplifies ordering while providing genuine Wilden parts.

The updated repair kits are part of Wilden's ongoing innovation of new technologies and programs to improve performance, customer satisfaction and VALUE!

Contact your authorized Wilden Distributor to order your parts kit.

FEATURES AND BENEFITS

- Less expensive
- Elimination of duplicate and unneeded parts
- Streamlined ordering
- Faster delivery
- Only quality Wilden parts
- Preserve Wilden factory warranties



Each Wet Kit and Air Kit can be applied to many different pump models to significantly reduce the number of kits required to cover Wilden's products and simplify ordering.

The New Wilden Wet Kit

The Wet Kit replaces the Elastomer Kit and includes only elastomers located on the wet side of the pump such as diaphragms, balls, seats, gaskets and o-rings (if required). No air side/ADS parts are included in the Wet Kit to eliminate part duplication.

KIT, WET, AA/B/C/DDD

SIZE (AA)

 $0.5 = 13 \text{ mm} (\frac{1}{2})$ 1= 25 mm (1")

 $1.5 = 38 \text{ mm} (1\frac{1}{2}")$

2 = 51 mm (2'')

3 = 76 mm (3'')

RUBBER

CONFIGURATION (B)

O = ORIGINAL

A = ADVANCED

D = ADVANCED "FIT"


H = HIGH PRESSURE

S = STALLION

F = BRAHMA (FLAP VALVE)

C = COMBO*

Combo kits are suitable for both Original and Advanced pumps (Advanced FIT not included)





DIAPHRAGMS (DDD)

BNS = BUNA-N (Red Dot)

NES = NEOPRENE (Green Dot) EPS = EPDM (Blue Dot)

FBS = SANITARY BUNA-N

FES = SANITARY EPDM (Two Blue Dots)

VTS = FKM (White Dot)

XBS = CONDUCTIVE BUNA-N (Two Red Dots) ²BNU = BUNA-N, ULTRA-FLEX™ (Blue Dot) ²EPU = EPDM, ULTRA-FLEX™ (Blue Dot)

²NEU = NEOPRENE, ULTRA-FLEX™

2VTU = FKM, ULTRA-FLEX™

FSS = SANIFLEX™ (Cream)

FWS = E-Z INSTALL SANITARY WIL-FLEX™ PUS = POLYURETHANE (Clear)

WFS = WIL-FLEX™ (ORANGE DOT)

²ZGS = E-Z INSTALL GEOLAST

²ZSS = E-Z INSTALL SANIFLEX™ (Cream) ²ZPS = E-Z INSTALL POLYURETHANE (Clear)

²ZWS = E-Z INSTALL WIL-FLEX™ (Orange Dot)

LEL = PTFE EPDM BACKED, IPD

TEU = PTFE w/EPDM BACK-UP

PUMP MATERIAL (C)

M = ALL METAL PUMPS

A = ALUMINUM ONLY**

S = SS/ALLOY C ONLY**

P = ALL PLASTIC PUMPS

TNU = PTFE w/ NEOPRENE BACK-UP

TSU = PTFE w/ SANIFELX™ BACK-UP

2TSS = FULL STROKE PTFE w/ SANIFLEX™

²TWS = FULL STROKE PTFE w/WIL-FLEX™

BACK-UP ³THU = PTFE w/ HIGH TEMP BUNA-N BACK-UP

¹Abbreviation for Thermoplastic Elastomers ²Only applies to 1½" through 3" models ³Only applies to ½" models

The New Wilden Air Kit

The Air Kit replaces the ADS Kit and contains a reduced number of parts, eliminating the air valve assemblyand muffler plate. All Air Kits will now include the air valve spool and are available only in the Air Kit*. All Air Kits are vacuum-sealed to maintain parts integrity and cleanliness.

* The T-Series version will provide the complete air valve assembly...

KIT, AIR, AA/BB/C/D/E/F

AIR DISTRIBUTION SYSTEM (AA)

T = TURBO

P = PROFLO

PX = PROFLO X PS = PROFLO SHIFT

H = HIGH PRESSURE

MODEL SIZES (BB)

 $0.5 = 13 \text{ mm} (\frac{1}{2}")$

1 = 25 mm (1") $1.5 = 38 \text{ mm} (1-1\frac{1}{2}")$

2 = 51 mm (2")

3 = 76 mm (3'')4 = 102 MM (4")

³ Turbo-Flo models only

CONFIGURATION (C)

A = ADVANCED AND ADVANCED FIT

O = ORIGINAL F = FLAP

 $C = COMBO^{1}$

PUMP MATERIAL (D)

M = METAL PUMPS

P = PLASTIC PUMPS $C = COMBO^2$

B = BRASS AIR VALVES3

M = METAL AIR VALVES

P = PLASTIC AIR VALVES

R = ANODIZED ALUMINUM AIR

PUMP AIR VALVE MATERIAL (E)

VALVES


D = BRASS AIR VALVES WITH OIL BOTTLE³



Copyright 2021 PSG®, a Dover company

Combo configurations are suitable for Original, Advanced, and Advanced FIT Pumps

² Combo pump material kits are suitable for metal and plastic pumps









22069 Van Buren Street Grand Terrace, CA 92313-5651 USA P: +1 (909) 422-1730 • F: +1 (909) 783-3440 wildenpump.com